brother

Brother

SOTI Connect Printer Management Setup Guide

Version 1.0

The Brother logo is a registered trademark of Brother Industries, Ltd. Brother is a registered trademark of Brother Industries, Ltd. © 2021 Brother Industries, Ltd. All rights reserved.

Other software and product names mentioned herein may be the trademarks or registered trademarks of their respective owners.

End-User License Agreement

IMPORTANT - PLEASE READ CAREFULLY:

This End-User License Agreement ("EULA") is a legal agreement between you and Brother Industries, Ltd. ("Brother", "we" or "our"), which governs your use of the Brother software (including associated materials or documents) provided with this EULA (collectively, "SOFTWARE"). If you agree to be legally bound by the terms and conditions of this EULA, you may use the SOFTWARE in accordance with the terms and conditions of this EULA. If you do not agree to the terms and conditions of this EULA, you obtain no license to the SOFTWARE. In such case, you may not use the SOFTWARE. **T**erms and Conditions.

1. Ownership.

All right, title and interest in and to the SOFTWARE (including all copyright and other intellectual property rights therein) are owned by Brother or its suppliers. The SOFTWARE is licensed but not sold.

2. Grant of License.

2.1 Brother grants you a non-exclusive license to install and use the copy of the SOFTWARE on your devices, to the extent necessary for intended use of Brother's products (including, but not limited to label printer products) for which such SOFTWARE will be used ("Brother Machine").

2.2 Brother further grants you a license to make one copy only of the SOFTWARE solely for archival and back-up purposes. Any such copy shall also reproduce all copyright and intellectual property right notices from the original.

2.3 Other than as expressly permitted by Sections 2.1 and 2.2 above, or where you have a right at law to do so (and such right cannot lawfully be excluded) you may not: (i) make any copies of the SOFTWARE (including associated documents or materials within the SOFTWARE such as, including but not limited to documents, pictures, illustrations and movies provided by Brother); (ii) modify the SOFTWARE; (iii) reverse engineer, disassemble, decompile or use the SOFTWARE to create any derivative work; (iv) rent, sub-license, transfer or lease the SOFTWARE; and (v) make available to download the SOFTWARE to the public.

2.4 With respect to your use of the SOFTWARE, you agree and undertake: (i) to keep all copies of the SOFTWARE secure and to maintain accurate and up-to-date records of the number and locations of all copies of the SOFTWARE; (ii) where you are a business entity, to supervise and control use of the SOFTWARE and ensure that the SOFTWARE is used by your employees and representatives in accordance with the terms of this EULA; and (iii) in no event shall Brother be liable for your alterations to, or modifications of, the whole or any part of the SOFTWARE to be combined with, or become incorporated in, any program other than designated by Brother. You shall take all responsibility for your alterations or modifications and their results.

3. WARRANTIES DISCLAIMER.

TO THE EXTENT ALLOWED BY LAW, THIS SOFTWARE IS PROVIDED TO YOU "AS IS" WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED. BROTHER SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, SATISFACTORY QUALITY, NON-INFRINGEMENT AND/OR FITNESS FOR A PARTICULAR PURPOSE.

4. Limitation of Liability.

IN NO EVENT SHALL BROTHER BE LIABLE FOR ANY LOSS OF PROFITS, LOSS OF BUSINESS OPPORTUNITIES, LOSS OF USE OF DATA, INTERRUPTION OF BUSINESS, OR FOR INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, EXEMPLARY OR CONSEQUENTIAL DAMAGES OF ANY KIND, ARISING OUT OF THE USE, INABILITY TO USE, OR THE RESULTS OF USE OF THE SOFTWARE, WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE. YOUR USE OF THE SOFTWARE IS ENTIRELY AT YOUR OWN RISK. SHOULD THE SOFTWARE PROVE DEFECTIVE, YOU ASSUME THE ENTIRE COST OF ALL SERVICE, REPAIR OR CORRECTION AND, TO THE EXTENT PERMITTED BY THE APPLICABLE LAW, YOU AGREE TO UNCONDITIONALLY WAIVE ALL STATUTORY OR OTHER RIGHTS THAT MAY BE HELD BY YOU AGAINST BROTHER IN RESPECT OF SUCH DEFECT. Notwithstanding the above, these terms do not purport to limit the statutory rights of a consumer that cannot be waived under the applicable law.

5. Cost, charge incurred for your use of the SOFTWARE.

You agree and understand that service(s) available in the SOFTWARE may be provided through any network communication and any cloud server as operated by Brother or its suppliers, and therefore, using this SOFTWARE, any communication charge due to utilization of such network and such cloud server will occur, and you shall bear such charge. In addition to the above charge, you are solely responsible for any costs or expenses incurred by you in connection with your use of the SOFTWARE. In no event shall Brother reimburse you for any above charge, costs or expenses.

6. The third party's service.

The SOFTWARE allows you to utilize third-party services and applications (collectively, "Third-Party Services") at your own discretion. The Third-Party Services are governed by the terms and conditions separately defined and provided by the third party. Use of such Third-Party Services is absolutely at your own expense and under your own responsibility, Furthermore, Brother shall not be liable for any errors, losses and damages incurred to you and your property, whether visible or not, arisen by use of the Third-Party Services, including but not limited to losses or damages caused:

i) By any change of designs, functions, structures or specifications of Third-Party Services;

ii) Any renewal or termination of Third-Party Services; or

iii) By any malfunctions or errors caused by or from the use of your computers, hardware devices, or software.

7. Connection of SOFTWARE and Brother Machine.

You shall acknowledge that when you connect the SOFTWARE and the online Brother Machine, you may be required to input valid ID and passwords for Third-Party Services. With respect to the security of ID, passwords and login information related to utilizing of Brother Machine, the SOFTWARE and Third-Party Services, you agree and undertake that you shall take all responsibility for the control of such security and in no event shall Brother be liable for any losses and damages in connection with the deficiency of your control. Brother shall not be liable for any troubles, disputes, and related damages incurred when you attempt to connect the SOFTWARE to an online Brother Machine owned, managed, or in control by you or any other third parties.

8. Malware

You may not knowingly use (including transmitting using the SOFTWARE) any software program in any way that could cause harm to the Brother Machine, the SOFTWARE or the network with which they may interact, including but not limited to computer viruses, Trojan horses or other programs whose effect is to negatively impact the operation, performance or security. Furthermore, you may not use the SOFTWARE to attempt unauthorized access to any service, system, data, account or network.

9. Term and Termination.

This EULA will become effective upon your acceptance and shall continue in effect unless you stop using the SOFTWARE. However, Brother may terminate this EULA without notice if you breach any of its provisions.

10. Export Regulations.

You may not export or re-export the SOFTWARE or any copy or adaptation thereof in violation of any applicable laws or regulations.

11. Governing Laws.

This EULA is governed by the laws of Japan and Japanese Courts shall have exclusive jurisdiction with respect to this EULA except with regards to enforcement in which case the jurisdiction of the Japanese Courts shall be non-exclusive. 12. Illegality.

If any of the provisions of this EULA shall be declared illegal or unenforceable in whole or in part, such provisions shall be severable and independent from the other provisions of this EULA, and the validity of the other provisions and of the entire EULA shall not be affected.

13. Third Party Rights.

The provisions of this EULA are intended only to have effect between Brother and yourself and are not intended to confer any benefit or right of enforcement upon any other person.

14. Personal License.

The rights granted by Brother hereunder are personal to you and you shall not be permitted to assign, transfer or otherwise make over to any third party the Software or the benefit or burden of this EULA or any of the rights granted hereunder.

15. Third-Party Software

The SOFTWARE may contain third-party software and/or Open-source software programs (collectively, "Third-Party Software"). As for details of the Third-Party Software, please refer to the terms and conditions separately defined. 16. Handling of Your Information.

When you use the SOFTWARE, information from the Brother Machine and the devices connected to the Brother Machine ("Device"), including but not limited to, product model, serial number, locale ID (regional information), OS type of your installation, firmware, use of each function of the SOFTWARE (collectively, "Device Data"), may be sent and recorded in a server which you control and use ("your server"). Device Data is not sent and recorded in our server and we cannot access your server nor make any change to Device Data. However, SOTI Inc., a software provider company, reserves the right to access the Device Data stored in your server. SOTI Inc. will use the Device Data for purposes you and SOTI Inc. agree separately between you and SOTI Inc. in a user agreement.

1. Introducti	on	1
1.1	System Configuration	2
1.2	Network Configuration	2
1.3	Definition of Terms	3
1.4	Supported Printers	3
1.5	What Brother Provides	3
2. Install the	SOTI Protocol Adapter and MQTT Broker	4
3. Set Up Yo	ur Brother Printer	5
3.1	Verify Printer Network Settings	5
3.2	Connect with HiveMQ or other MQTT Broker (HiveMQ)	5
3.3	Set up using the BPM	5
3.4	Set up Using Embedded Web Server (EWS)	7
4. Managing	Brother Printers with SOTI Connect 1	0
4.1	Printer Settings 1	0
4.2	Printer Status Display/Error Log1	3
4.3	Items that can be sent to the printer via the SOTI file store function	4

1. Introduction

This Software User's Guide is intended for IT administrators who want to manage Brother printers with SOTI Connect.

SOTI Connect is an Internet of Things Framework (IOTF), a flexible, extensible system for managing devices in an Internet of Things (IoT) network. Device administrators can use the system to remotely query device state, update the software on devices, configure, reboot, and perform other actions permitted by the device manufacturer.

SOTI Connect does not require devices to support a specific management or communication protocol. If you need to use SOTI Connect to manage a new device with a different protocol, SOTI can create a Protocol Adapter and a Protocol Definition for the new device, so you can manage the device without upgrading the core system.

The system generates the Management User Interface (UI) from the device's XML description.

1.1 System Configuration

There are two types of SOTI Connect system configurations: Cloud-Based and On-Premise-Based **Cloud-Based**



On-Premise-Based



1.2 Network Configuration



1.3 Definition of Terms

Term	Description		
MDM (Mobile Device Management)	A management system for mobile devices, including smartphones or		
	peripheral equipment.		
SOTI Connect	An IoT solution that provides complete lifecycle management of IoT devices		
	within an organization.		
SOTI Protocol Adapter	Software provided by SOTI to connect SOTI Connect and the printer via		
	MQTT broker.		
MQTT (Message Queuing Telemetry	A lightweight, publish-subscribe network protocol that transports messages		
Transport)	between devices.		
MQTT Broker	Software running on a computer (running on-site or in the cloud; acts as a		
	post office).		
HiveMQ	An MQTT broker: a messaging platform for efficient, reliable data		
	movement to and from connected IoT devices and enterprise systems.		

1.4 Supported Printers

Model	Supported Firmware Version	Supported Interface
TJ-4420TN		
TJ-4520TN		
TJ-4620TN	B1.17.S22 or later	
TJ-4422TN		VVIREIESS LAIN
TJ-4522TN		

1.5 What Brother Provides

Item	Explanation
Software User's Guide	This document
Brother Printer Management	Printer setup tool for Windows for TJ-44/45/46 printers, as listed in section 1.4
Tool (BPM)	Use version 1.0.0.40 or later

2. Install the SOTI Protocol Adapter and MQTT Broker

Install SOTI Protocol Adapter and an MQTT Broker, such as HiveMQ.

Record the following information for setting up the printer:

- $\cdot\,$ IP Address of the Windows server where the MQTT broker is installed
- · MQTT Tenant ID
- · Certificate file (if needed)

Cloud-Based Installation



On-Premise-Based Installation



3. Set Up Your Brother Printer

3.1 Verify Printer Network Settings

Your printer must be connected to a network.

For more information on setting up your printer, see your model's *User's Guide* on the Brother support website at <u>support.brother.com</u>.

3.2 Connect with HiveMQ or other MQTT Broker (HiveMQ)

Do one of the following:

To set your printer up using the Brother Printer Management Tool (BPM), see 3.3 Set up using the BPM.

To set your printer up using the printer's Embedded Web Server (EWS), see <u>3.4 Set up using Embedded Web Server</u> (EWS).

3.3 Set up using the BPM

1. Open the BPM.

X	Brother	Print	er Manageme	ent Tool V1.0.0.36							-		×
(/	Group Nar All	me: ~	l	Jsers	Alert	Group		Setup		Manual Nar	ne	Language English	•
Γ			Status	Printer	IP Address	Model	Version	Serial No	Mileage	Interface			
			@	PS-705D5D		TJ-4420TN	B1.17.S18.L	. U65921G0	5.9048	ŵ			
l				File Ma	nager	Tool		tup		Function	Bitmap	Font Manage	er

2. Select the printer or printers you want, and then click Printer Function.

🔏 Brother Prin	ter Manager	ment Tool V1.0.0.36							_		×
Group Name:										Languag	е
All ~	,	Users	Alert	Group		Setup		Manual Na	me	English	\sim
	Status	Printer	IP Address	Model	Version	Serial No	Mileage	Interface			
	9	PS-705D5D		TJ-4420TN	B1.17.S18.I	U65921G0	5.9048				
								_			
Printer Con	nfiguration	File Ma	nager Command	d Tool	RTC Se	tup	Printer Fur	nction	Bitmap	Font Manag	er

3. Click SOTI Setup.

Print	ter Function	×
	Calibrate	
	Reset Printer	
	Factory Default	
	Print Test Page	
	Configuration Page	
	Ignore AUTO.BAS	
	Exit Line Mode	
	Enter Line Mode	
	Dump Text	
	Wi-Fi Default	
l	SOTI Setup	

4. Fill in the SOTI Setup fields.

AQTT Server Configuration	1 -			
Host	Tenant ID:			
Port	Secured:	TLS	O None	
Certicficate Files				
MQTT Cert			Browse	Clear
			Browse	Clear
File Store Cert:				

a. The Host, Port, and Tenant ID fields are required.

Select a **Secured** radio button based on your server's security settings.

If needed, click the **Browse** button to upload the certification file.

Setting	Value	Description
Host	-	IP Address of the Windows server where the MQTT broker is installed
Tenant ID	-	Identifier of the SOTI Protocol Adapter
		Leave blank if you have only one SOTI Protocol Adapter on your Windows
		Server.
Port	1883 or 8883	-
Secured	None or TLS	-
MQTT Cert	-	Use to enable highly secured communication between the Windows Server
		and the printer.
File Store Cert	-	Use to enable the highly secured communication between the file server
		and the printer.
		SOTI Connect will send the files (for example, firmware files) to the printer
		via the file server.

b. Click the Set button to save your settings. The printer restarts.

Note

When you register the printer on SOTI Connect, click the **Get** button.

If the printer is successfully connected to the SOTI, the status icon on SOTI Setup window will light in green.

• To clear the SOTI settings, click the Initialize SOTI settings button.

3.4 Set up Using Embedded Web Server (EWS)

Embedded Web Server (EWS) allows you to configure your printer using a web browser.

1. Type http://printer_IP_address in your web browser's address bar, where printer_IP_address is the printer's IP address or the print server name.

For example, if the printer's IP address is 192.168.1.2, type: http://192.168.1.2

For more information on accessing EWS, go to support.brother.com.

TJ-4420TN Print Server 🛛 🗙 📑					
	Printer Informa	tion			
brothor	Version :	TJ-4420TN Ve	rsion B1.17.S18.I01 E	ZD	
	Serial No :	U65921B0T11	1106	Checksum :	19503566
	Milage :	0.187402 Km			
Configuration	SOTI				
General	Refresh	S	et		
Adjust	Printer Power Ll	n Time: 2021.	06-23 13:17		
Media	MOTT Owner of		00-20 10.17	7	
Calibration	MQTT Server :				
Serial	MQTT Server Po	ort :			
<u>Network</u>	MQTT Secured:	От	S None		
<u>Wi-Fi</u>	MOTTON			7	
Mail	MQTTCA:				
Clock	File Store CA:				
Password	SOTI Tenant ID:				
Tools	SOTI Agent ID:	TJ-44	20TN-U65921B0T111	106	
Function	Total Log	0			
Upgrade					
Status					
SOTI					
File					
Log					

2. In the Tools menu, click File to upload the certificate file to the printer (if needed).

TJ-4420TN Print Server X					
	Printer Informat	tion			
brothor	Version :	TJ-4420	TN Version B1.17.S18.	I01 EZD	
	Serial No :	U65921	B0T111106	Checksum :	19503566
	Milage :	0.18740	02 Km		
Configuration	SOTI				
General	Refresh		Set		
Adjust	Printer Power Ur	Time	2021-06-23 13:17		
Media	MOTT Server				
Calibration	WQTT Server.				
Serial	MQTT Server Po	ort :			
Network	MQTT Secured:		O TLS None		
<u>Wi-Fi</u>	MOTT CA ·				
Mail	Might on.				
Clock	File Store CA:				
Password	SOTI Tenant ID:				
Tools	SOTI Agent ID:		TJ-4420TN-U65921B	DT111106	
Function	Total Log		0		
Upgrade					
Status					
SOTI					
File					
Log					

3. Click the **Upload File** drop-down list, and then select **FLASH**. Browse to the certificate file you want, and then click **Brows**.

Printer File	
DRAM Device :	Format
FLASH Device :	Format
Upload File :	FLASH V Browse
Upload	Refresh

4. In the **Tools** menu, click **SOTI** to configure the necessary settings.

TJ-4420TN Print Server ×	(📑					
	Pri	nter Informatio	on			
broth	Ver	sion :	TJ-4420	TN Version B1.17.S18	.I01 EZD	
OOUI	Ser Ser	ial No :	U65921E	B0T111106	Checksum :	19503566
	Mila	age :	0.187402	2 Km		
Configuration	so	ті				
General	9	Refresh		Set		
<u>Adjust</u>	Prir	nter Power Up	Time:	2021-06-23 13:17		
Media	MC	TT Server	rinio.			
Calibration	IVIG	IT Server.				
Serial	MQ	TT Server Por	t:			
Network	MQ	TT Secured:		O TLS None		
<u>Wi-Fi</u>	MG	TT CA ·				
Mail	in s					
Clock	File	Store CA:				
Password	SO	TI Tenant ID:				
	SO	TI Agent ID:		TJ-4420TN-U65921B	0T111106	
Function	Tot	al Log		0		
Upgrade						
Statue						
SOTI						
File						
Log						

5. Click the **Set** button to save your settings. The printer restarts.

🕅 Note

When the printer is successfully connected to SOTI, 'SOTI connected' will appear in the Total Log field.

SOTI	
Refresh	Set
Printer Power Up Time:	2021-06-23 13:17
MQTT Server :	
MQTT Server Port :	
MQTT Secured:	O TLS ● None
MQTT CA :	
File Store CA:	
SOTI Tenant ID:	
SOTI Agent ID:	TJ-4420TN-U65921B0T111106
Total Log	0

4. Managing Brother Printers with SOTI Connect

4.1 Printer Settings

	Settings	Description
1	Device Details	Approval Date
		Description
		ld
		Last Update
		Device Type
		Protocol Adapter
		Member of Groups
		Protocol Instance
2	Device Information	Manufacturer
		Model
		Serial Number
		TPH Resolution
		DRAM
		Flash Memory
		Free DRAM
		Free Flash Memory
		Version
		Wi-Fi Version
		Bluetooth Version
		Host Name
		FQDN
3	Printer Statistics	Printer Mileage
		TPH Odometer
		TPH Serial Number
		TPH Cleaning
		Total Label Count
		Printer Cutter Counter
		Cutter Counter
		Cutter Serial Number
		Ribbon Remaining
		Last Power On Time

	Settings	Description
4	TPH Care	TPH Care Support
		TPH Care Enable
		Unhealthy Dot Quantity
		Unhealthy Dot Quantity Warning Threshold
5	System Control	Display Language
		System LCD Brightness
		"Paper Low" Warning Threshold
		"Ribbon Low" Warning Threshold
		System Menu Lock Enabled
		System Menu Password
		"My Favorite" Menu Lock Enabled
		System Date Format
		System Time Format
		System Date
		System Time
6	Serial Port Settings	Serial Port Baud Rate
		Serial Port Data Bits
		Serial Port Parity
		Serial Port Stop Bits
7	MQTT Information	MQTT Server Address
		MQTT Port
		MQTT Device Name
		MQTT Device ID
8	Network Settings	Wired LAN Print Data Port
		Automatically Obtain Wired LAN IP Address
		Wired LAN IPv4 Address
		Wired LAN Subnet Mask
		Mired LAN Secondary DNS Address
		Wired LAN Secondary DNS Address
		Wired LAN MAC Address
		vvired LAN Ethernet Speed

	Settings	Description
9	Wi-Fi settings	Wi-Fi Print Data Port
		Automatically Obtain Wireless LAN IP Address
		Wireless LAN IPv4 Address
		Wireless LAN Subnet Mask
		Wireless LAN Gateway
		Primary DNS Server Wireless LAN IP Address
		Wi-Fi Second DNS
		Wireless LAN SSID
		Wireless LAN Security Mode
		Wireless LAN WEP Key Index
		Wireless LAN WEP Key
		Wireless LAN EAP Mode
		Wireless LAN CA Certificate Filename
		Wireless LAN Client Certificate Filename
		Wireless LAN Private Key Filename
		Wireless LAN EAP Username
		Wireless LAN MAC Address
9	Bluetooth Settings	Bluetooth Connection Name
		Bluetooth PIN
		Bluetooth Mode
		Bluetooth MAC Address
10	Installed Modules	Wi-Fi
		Bluetooth
		Cutter
11	Media Settings	Print Speed
		Darkness
		Paper Width
		Paper Height
		Print Direction
		Print Mode
		Offset
		Shift X
		Shift Y
		Reference X
		Reference Y
		Code Page
		Country Code

	Settings	Description
12	Sensor Settings	Media Sensor Type
		Gap Size
		Black Line Size
		Threshold Detection
		Maximum Sensor Detection Length
		Minimum Paper Length
		Maximum Paper Length
13	Device Flag History	FLAG

Supported actions

Action	Explanation
Print Test Page	Print a test page.
Factory Reset	Reset all printer settings to the factory settings.
Reboot	Reboot the printer.

4.2 Printer Status Display/Error Log

Error	Solution
Print Hoad Open	Close the print head mechanism,
	making sure it locks into place.
Papar Jam	Remove the paper jammed inside the
	print mechanism.
Paper Out	Install the paper roll.
Ribbon Jam	Remove the ribbon jammed inside
	the print mechanism.
Ribbon Out	Install the ribbon roll.
Cuttor Error	Clean the cutter unit and make sure
	the cutter is installed correctly.
Dowor Error	Reduce the print speed or check the
	power supply.
	Make sure the Thermal Print Head
TPH Broken	(TPH) cable is connected to the TPH
	correctly.
	Stop the operation to cool down the
	printer.
Matar Overbaat	Stop the operation to cool down the
Motor Overneat	printer.
Deviced en land	Make sure that no foreign material is
	stuck on the media rewinder.
Out of Momon (Delete unnecessary files in the
	printer's FLASH/DRAM.

Alert	Explanation
Cancel Print Queue	Print job has been cancelled.
Printer Pause	Print job has been paused.
Printer Resume	Print job has been resumed.
File Download Complete	File download has completed.
File Download Host Not Found	Cannot find the host to download.
File Download File Not Found	Cannot find the file to download.
File Download Abort	File download timeout or error.
Firmware Upgrade Completed	Firmware upgrade completed.
Firmware Upgrade Timeout	Firmware upgrade timeout.

4.3 Items that can be sent to the printer via the SOTI file store function

Setting	File extension	Comment
Firmware	EZD/EZS	
AUTOBAS	BAS	
FBPL printing file	тхт	
FBPL configuration file	TXT/PRN/SPL	

This manual describes setting up a Brother printer for use with SOTI. For instructions and troubleshooting specifically on SOTI, refer to the SOTI resources at https://www.soti.net/products/soti-connect/. Help page:

https://www.soti.net/soticonnect/v1.1/en/index.html

For more information about setting up HiveMQ as MQTT, contact your local Brother dealer.