

Function	Option Parameter	Value
Media Type	BRMediaType=PlainDuplex	Plain Duplex Paper
	BRMediaType=Plain	Plain Paper
	BRMediaType=Inkjet	Inkjet Paper
	BRMediaType=BrotherGlossyR	Brother BP71 Photo Paper
	BRMediaType=BrotherBP60Matte	Brother BP60 Matte Paper
	BRMediaType=Glossy	Other Photo Paper
	BRMediaType=Transparencies	Transparencies
	BRMediaType=HagakiAtena	HagakiAtena
	BRMediaType=HagakiUra	HagakiUra
Print Quality	BRResolution=PlainFast	PlainFast
	BRResolution=PlainNormal	PlainNormal
	BRResolution=Fast	Fast
	BRResolution=Normal	Normal
	BRResolution=Photo	Photo
	BRResolution=Best	Best
Bi-Directional Printing	BRBiDir=OFF	
	BRBiDir=ON	
Paper Type	PageSize=A3	A3
	PageSize=BrA3_B_S	A3 (Borderless)
	PageSize=B4_S	JB4
	PageSize=Tabloid_S	Tabloid
	PageSize=BrLedger_B_B	Tabloid (Borderless)
	PageSize=A4	A4
	PageSize=BrA4_B	A4 (Borderless)
	PageSize=Letter	Letter
	PageSize=BrLetter_B	US Letter (Borderless)
	PageSize=Legal	Legal
	PageSize=Executive	Executive
	PageSize=B5	JIS B5
	PageSize=A5	A5
	PageSize=A6	A6
	PageSize=BrA6_B	A6 (Borderless)
	PageSize=BrPostC4x6_S	4 x 6 in
	PageSize=BrPostC4x6_B	4 x 6 in (Borderless)
	PageSize=BrIndexC5x8_S	5 x 8 in
	PageSize=BrPhotoL_S	3.5 x 5 in
	PageSize=BrPhotoL_B	3.5 x 5 in (Borderless)
	PageSize=BrPhoto2L_S	5 x 7 in
	PageSize=BrPhoto2L_B	5 x 7 in (Borderless)
	PageSize=Postcard	Postcard 1
	PageSize=BrHagaki_B	Postcard 1 (Borderless)
	PageSize=DoublePostcardRotated	Postcard 2 (Double)
	PageSize=EnvC5	C5 Envelope
	PageSize=EnvDL	DL Envelope
	PageSize=Env10	Com-10
	PageSize=EnvMonarch	Monarch
	PageSize=EnvYou4	Y4 Envelope
	PageSize=EnvCho3	N3 Envelope
	PageSize=EnvCho4	N4 Envelope
PageSize=EnvKaku2	K2 Envelope	

Function	Option Parameter	Value
Paper Thickness	BRColorPaperThick=Regular	Regular
	BRColorPaperThick=Thick	Thick
	BRColorPaperThick=Env	Envelope
Paper Source	BRInputSlot=AutoSelect	
	BRInputSlot=Tray1	
	BRInputSlot=Tray2	
Color / Grayscale	BRMonoColor=Color	Color
	BRMonoColor=Mono	Grayscale
Color Mode	BRColorMatching=Natural	Natural
	BRColorMatching=Vivid	Vivid
	BRColorMatching=None	None
Change Data Transfer Mode	BRJpeg=Recommended	Recommended Setting
	BRJpeg=QualityPrior	Improved Print Quality
	BRJpeg=SpeedPrior	Improved Print Speed
Halftone Pattern	BRHalfTonePattern=Diffusion	Diffusion
	BRHalfTonePattern=Dither	Dither
Color Enhancement	BRColorEnhancement=OFF	
	BRColorEnhancement=ON	
Slow Drying Paper	BRSlowDrying=OFF	
	BRSlowDrying=ON	
Two-Sided	Duplex=DuplexTumble	Short-Edge Binding
	Duplex=DuplexNoTumble	Long-Edge Binding
	Duplex=None	Off
Advanced Duplex Settings	BRDuplexMode=Normal	Normal
	BRDuplexMode=Duplex1	Duplex 1 (Slower print speed)
	BRDuplexMode=Duplex2	Duplex 2 (Slower print speed & less ink)
Brightness	BRBrightness=N N=numerical value (min -20 - max 20)	
Contrast	BRContrast=N N=numerical value (min -20 - max 20)	
Red	BRRed=N N=numerical value (min -20 - max 20)	
Green	BRGreen=N N=numerical value (min -20 - max 20)	
Blue	BRBlue=N N=numerical value (min -20 - max 20)	