

Function	Option Parameter	Value
Media	MediaType=Plain	Plain Paper
	MediaType=Thin	Thin Paper
	MediaType=Thick	Thick Paper
	MediaType=Thicker	Thicker Paper
	MediaType=BOND	Bond Paper
	MediaType=Env	Envelopes
	MediaType=EnvThick	Env. Thick
	MediaType=EnvThin	Env. Thin
	MediaType=Recycled	Recycled Paper
	MediaType=Label	Label
Media	MediaType=PostCard	PostCard
Print Quality	BRResolution=600dpi	Normal (600 x 600dpi)
	BRResolution=600x2400dpi	Fine (2400dpi class)
Media Size	PageSize=A4	
	PageSize=Letter	
	PageSize=Legal	
	PageSize=Executive	
	PageSize=A5	
	PageSize=PRA5Rotated	A5 Long Edge
	PageSize=A6	
	PageSize=B5	
	PageSize=B6	
	PageSize=JISB5	JIS-B5
	PageSize=JISB6	JIS-B6
	PageSize=EnvDL	DL Envelope
	PageSize=EnvC5	C5 Envelope
	PageSize=Env10	#10 Envelope
	PageSize=EnvMonarch	Monarch Envelope
	PageSize=Br3x5	3 x 5
	PageSize=BrA4Long	A4Long
	PageSize=FanFoldGermanLegal	Folio
	PageSize=EnvPRC5Rotated	DL Long Edge
	PageSize=PostCard	Hagaki
	PageSize=EnvYou4	Envelope #4
	PageSize=EnvChou3	Envelope MAX
	Media Source	InputSlot=AutoSelect
InputSlot=Tray1		Tray1
InputSlot=Manual		Manual Select
Color Or Mono	BRMonoColor=Auto	
	BRMonoColor=FullColor	
	BRMonoColor=Mono	
Color Match	BRColorMatching=Normal	
	BRColorMatching=Vivid	
	BRColorMatching=None	
Enhance Black Printing	BREnhanceBlkPrt=OFF	
	BREnhanceBlkPrt=ON	
Brightness	BRBrightness=xx	-20乃至20
Contrast	BRContrast=xx	-20乃至20
Red Key	BRRed=xx	-20乃至20
Green Key	BRGreen=xx	-20乃至20
Blue Key	BRBlue=xx	-20乃至20
Saturation	BRSaturation=xx	-20乃至20
Improve Gray Color	BRGray=OFF	
	BRGray=ON	
Toner Save Mode	TonerSaveMode=OFF	
	TonerSaveMode=ON	
Improve Print Output	BRImproveOutput=OFF	
	BRImproveOutput=BRLessPaperCurl	Reduce Paper Curl
	BRImproveOutput=BRFixIntensity	Improve Toner Fixing